

MICRO QUAD II

- with Acoustic Panel

INSTALLATION - PENDANT MOUNT

PAGE 1 of 4



PLEASE ENSURE ELECTRICAL CIRCUIT IS DISCONNECTED BEFORE INSTALLATION



NEVER TOUCH THE YELLOW PORTION OF THE LED CHIP OR DAMAGE MAY OCCUR




Figure 1

NOTES:



1. Place the acoustic panels to a flat and clean surface
2. Insert the fixture assembly to the acoustic panel and secure it with supply tapping screws - see Figure 1


MICRO QUAD II

- with Acoustic Panel

INSTALLATION - PENDANT MOUNT

PAGE 2 of 4

-  PLEASE ENSURE ELECTRICAL CIRCUIT IS DISCONNECTED BEFORE INSTALLATION
-  NEVER TOUCH THE YELLOW PORTION OF THE LED CHIP OR DAMAGE MAY OCCUR



NOTES:

1. Mount the couplers to ceiling using appropriate fasteners -NOT INCLUDED- according to structure of the ceiling - see Figure 3
2. Pass the aircraft cable through the cap, fasten the cap to the coupler
3. Make all necessary wiring connections and attach the canopy using finial provided - see Figure 4
4. Lift the fixture and attach the loose ends of the aircraft cable to the cable glider - see Figure 5
5. Level the fixture using the cable gliders, to release the grip lock, press down on the tip of the mechanism, if desired, clip the excess aircraft cables after the fixture is level



PLEASE ENSURE ELECTRICAL CIRCUIT IS DISCONNECTED BEFORE INSTALLATION





NEVER TOUCH THE YELLOW PORTION OF THE LED CHIP OR DAMAGE MAY OCCUR


INSTALLATION INSTRUCTION FOR "S1" MOUNTING

1. Remove the 2x 8-32 screws and the drivers' box cover
2. Remove the necessary knockouts
3. Attach the conduits "NOT SUPPLIED"
4. Make the wiring connections
5. Re-attach the cover and secure it with the supplied screws


Use the mounting brackets to secure the box in place



SINGLE REMOTE BOX



MULTIPLE REMOTE BOX



IMPORTANT NOTE: When more than one remote box is supplied, they all must be connected to the same power supply branch circuit

MICRO QUAD II

- Handling a Fixture

INSTALLATION - PENDANT MOUNT


PAGE 4 of 4




PLEASE ENSURE ELECTRICAL CIRCUIT IS DISCONNECTED BEFORE INSTALLATION



NEVER TOUCH THE YELLOW PORTION OF THE LED CHIP OR DAMAGE MAY OCCUR



Lift the fixture and follow the steps, do not flex the fixture and make sure it is flat at all times



IMPORTANT NOTE: Fixture with LED - "DO NOT TOUCH THE LED"